



Remote Display Terminal (Mx-5010)

The remote terminals utilise the same graphical LCD user interface that can be found on the MxPro 5 series fire panels and are based upon the same advanced, flash based, microprocessor technology.

The MxPro 5 panels and remote terminals can communicate over the same 2-core network cable.

They feature an integral network interface incorporating a special screen termination to prevent mains frequency earth-loop currents flowing between network nodes.

The Ad-NeT network operates as a true peer-to-peer system with full cross panel reporting, control and cause-and-effect functionality of up to 2000 zones.

All remote terminals incorporate buzzer mute, view, enable/disable and test facilities with dedicated system and navigation keys for simple user control.

The display information is fully programmable by individual zone or sector and can display any combination of fires, faults, pre-alarms or plant alarms. E.g. can display all information in its own sector, but can only show fire signals from other sectors of a building.





Features

The RDT has additional control keys for Mute which allows other network panels' warning buzzer to be muted Fully on-site programmable via on-board alphanumeric keypad or PC configuration tools.

View all information from across the network

By using flash memory and an advanced graphical display the remote terminals can be easily configured to operate in virtually any language, with any character set and allows for the installer's logo and company details to be displayed on the LCD display during normal operation.

Networked for system display or control



Key Features

Programmable switch input Graphical LCD Display Ad-NeT/Ad-NeT+ Compatible Slide-in Labels

Small, Robust & compact 24V DC Operating voltage 3 Year Warranty Disable/enable options

| Display | White backlit 240x64 graphical LCD |
|----------------------------|---|
| LED Indicators | 1 red (1 x Fire, 1 x Alarm), 1 green (Power) & 3 amber (Fault & System) |
| Keypad | Alpha numeric keypad, navigation keys & on-board buzzer mute facility |
| Controls | System keys for Mute |
| Key-Switch Input | Optional level 2 access enable key switch |
| Power Supply Input | 24 VDC, 115mA (/FT: 150mA) operating range 15-30V |
| External Supply Monitoring | Monitored external fault input |
| Number of Fire Zones | 2000 |
| USB/Serial Ports | 1 x USB |
| Programming | Via on-board keypad or PC running Windows tools |
| Enclosure | Steel IP30 |
| Cable Entry | 20mm knock-outs. 4 x top and 4 x rear |
| Colour | RAL 7035 |
| Size H x W x D mm | Enclosure: 218 x 300 x 44 Back box only (when recessing) 218 x 300 x 30 |
| Metalwork Options | Semi flushing bezel, special finishes including stainless & chrome |

Order Codes and Options

Mx-5010: (RDT) Remote Display Terminal Mxm-518(F)*:

Access Enable key-switch Spare peripheral Fault Tolerant Fault Tolerant version Mx-5010/FT: Mxs-028: Semi-Flushing bezel Mxm-521: network interface

Add - Fitted (F)*: